



Incorrectly installing this product will negatively impact function and lifespan. If you are unsure please contact a professional.

Placement: In order to get the most from your hardware, please take extra care to ensure that you measure and mark the position of the hardware before drilling any holes or fixings.

1. Prepare the door by ensuring the surface of the door is clean and free from debris.
2. Using the Flush Pull as a guide, mark the size of the mortice required to accommodate the Back Box into the door surface. Taking care to ensure the markings are level and aligned parallel to the door edge. If fitting a pair as a set, ensure that the position matches on both sides of the door.
3. With a chisel, begin morticing out the marked size to the appropriate depth so that the back of the Flush Pull's Face Plate is level with the Door's surface. (Fig 1). Check the size as you work, making sure to not mortice a hole too deep into the door. If the Flush Pull's Back Box is rounded or has circular elements, a drill bit of the same diameter may be used. (Fig 2).
4. Insert the Flush Pull into the mortice, remove any excess swarf and if necessary use a rubber mallet to tap the flush pull into place. Take care to cover the surface so as to not damage the finish.
5. Flush pulls may come with fixing screws that are either face-fix or located in the inner recess of the pull. Once the Flush Pull is in situ, drill small pilot holes to accommodate the provided screws, and hand secure the fixings.
6. Test operation and make sure that the Flush Pull is secure in the frame before finishing installation.

